

Customer service: service@abbkine.com

Technical support: support@abbkine.com

Website: https://www.abbkine.com

## CheKine™ Micro Plant Soluble Sugar Assay Kit

Cat #: KTB1320

Size: 96 T

[ <u>;</u> ]	Micro Plant Soluble Sugar Assay Kit		
REF	<b>Cat #</b> : KTB1320	LOT	Lot #: Refer to product label
	Detection range: 0.0125-0.5 mg/mL		Sensitivity: 0.0125 mg/mL
	Applicable samples: Plant		
X	Storage: Stored at 4°C for 6 months, protected from light		

## **Assay Principle**

Carbohydrates are one of the important components of plant bodies, and are also the main raw materials and storage materials for metabolism. Soluble sugars refer to the reducing monosaccharides in the sample, sucrose and maltose that can be hydrolyzed into reducing monosaccharides under the determination conditions of this method, and starch that can be partially hydrolyzed into glucose. The detection principle is anthrone colorimetry. It can be used for the determination of soluble monosaccharides, oligosaccharides and polysaccharides. It has the advantages of high sensitivity, simplicity and speed, and suitable for the determination of trace samples.

#### **Materials Supplied and Storage Conditions**

	Size	- Storage conditions	
Kit components	96 T		
Anthrone	1	4°C, protected from light	
Solvent	10 mL	4°C	
Glucose Standard	10 mg	4°C	

# Materials Required but Not Supplied

- Microplate reader or visible spectrophotometer capable of measuring absorbance at 620 nm
- 96-well plate or microglass cuvette
- · Ice maker, centrifuge
- Incubator or metal bath
- · Precision pipettes, disposable pipette tips
- Deionized water
- · Concentrated sulfuric acid
- Homogenizer



## **Reagent Preparation**

**Working Solution:** Add 2.5 mL Solvent into Anthrone, and fully dissolve it for later use. If it is difficult to dissolve, it can be heated and stirred. The remaining working solution can be stored at 4°C for one week.

**Glucose Standard:** Before use, add 1 mL deionized water to the 10 mg Glucose Standard to prepare 10 mg/mL standard substance, which could be stored at 4°C for one week.

Setting of Standard curve: Further dilute the standard to 0.5, 0.2, 0.1, 0.05, 0.025, 0.0125 mg/mL standard with deionized water, as shown in the following table:

Num.	Volume of Glucose Standard	Volume of Deionized Water	Concentration
Std.1	50 μL 10 mg/mL	950 µL	0.5 mg/mL
Std.2	80 μL of Std.1 (0.5 mg/mL)	120 µL	0.2 mg/mL
Std.3	100 µL of Std.2 (0.2 mg/mL)	100 µL	0.1 mg/mL
Std.4	100 µL of Std.3 (0.1 mg/mL)	100 µL	0.05 mg/mL
Std.5	100 µL of Std.4 (0.05 mg/mL)	100 µL	0.025 mg/mL
Std.6	100 µL of Std.5 (0.025 mg/mL)	100 µL	0.0125 mg/mL

#### **Sample Preparation**

Plant: Weigh about 0.1 g sample, add 1 mL deionized water to homogenize it or grind it into homogenate, pour it into a centrifuge tube with a cap, take incubator or metal bath at 95°C for 10 min (cover tightly to prevent water loss), after cooling, Centrifuge at 8,000 g for 10 min at 25°C, take the supernatant into 10 mL test-tube, volume it to 10 mL with deionized water, and shake well for standby.

Note: If the protein concentration of the sample is need to determined, it is recommended to use Abbkine Cat #: KTD3001 Protein Quantification Kit (BCA Assay) to measure the protein concentration of the sample.

#### **Assay Procedure**

1. Preheat the microplate reader or Visible spectrophotometer for more than 30 min, and adjust the wavelength to 620 nm, Visible spectrophotometer was returned to zero with deionized water.

2. Sample measurement (the following operations are operated in the EP tube):

Reagent	Blank Tube (μL)	Test Tube (μL)	Standard Tube (µL)
Sample	0	40	0
Standard	0	0	40
Deionized Water	80	40	40
Working Solution	20	20	20
Concentrated Sulfuric Acid	200	200	200

3. Mix well, incubate in 95°C water bath or metal bath for 10 min (cover tightly to prevent water loss), cool to room temperature, take 200  $\mu$ L into 96-well plate or microglass cuvette, and read the absorbance values of the blank tube, standard tube and test tube at 620 nm, calculate  $\Delta A_{Test} = A_{Test} - A_{Blank}$ ,  $\Delta A_{Standard} = A_{Standard} - A_{Blank}$ .

Note: Only one blank tube needs to be made. In order to guarantee the accuracy of experimental results, need to do a pre-experiment with 2-3 samples. If the  $\Delta A_{Test}$  values are higher than 1.6, dilute sample with deionized water and repeat this assay, multiply the results with the dilution factor. Concentrated sulfuric acid is highly corrosive, please handle it



2/3

Version 20230327

carefully.

# **Data Analysis**

Note: We provide you with calculation formulae, including the derivation process and final formula. The two are exactly

equal. It is suggested that the concise calculation formula in bold is final formula.

1. Drawing of standard curve:

With the concentration of the standard solution as the y-axis and the  $\Delta A_{Standard}$  as the x-axis, draw the standard curve.

2. Calculating the content of soluble sugar:

According to the standard curve, the  $\Delta A_{Test}$  is substituted into the formula (x) to calculate the sample concentration y (mg/mL).

(1) Calculated by protein concentration

soluble sugar (mg/mg prot)=(y×V<sub>1</sub>)÷(V<sub>1</sub>×Cpr)=y÷Cpr

(2) Calculated by fresh weight of samples

soluble sugar (mg/g fresh weigh)= $(y \times V_1) \div (W \times V_1 \div V_2)=10 \times y \div W$ 

Where: V<sub>1</sub>: sample volume added, 0.04 mL; Cpr: sample protein concentration, mg/mL; W: fresh weigh of samples, g; V<sub>2</sub>: the volume of total samples, 10 mL.

# **Typical Data**

Typical standard curve:



OD620

Figure 1. Standard curve of Glucose Standard assay, data provided for demonstration purposes only. A new standard curve must be generated for each assay

# **Recommended Products**

Catalog No.	Product Name	
KTB1300	CheKine™ Micro Glucose Assay Kit	
KTB1100	CheKine™ Micro Lactate Assay Kit	

## **Disclaimer**

The reagent is only used in the field of scientific research, not suitable for clinical diagnosis or other purposes.

